

SlushPlow Install

Congratulations on purchasing a Slush Plow. This attachment for your new snow blower will push snow and slush. The attachment is easy to install, just follow the instructions that have been provided for you. Please make sure the size of the plow is larger than the blower housing. If the plow is smaller than the blower housing, please return and purchase the correct size plow. Please be aware the snow blower must have a transmission for this attachment to work. The transmission must be in good condition for the attachment to work. If the transmission slips, take it to a repair shop for a simple fix or adjustment. **WARNING** engine must be turned off when installing and uninstalling plow.

(Note that some models have holes pre-drilled from the manufacture. Toro, MTD, Cub Cadet, Sears, Troy Bilt, Simplicity, Snapper (do not have pre-drilled holes). Ariens models only have these holes. If the holes line up with the brackets you can accommodate those models or you must drill new holes and follow the instructions.)

Steps:

1) Assemble shown on picture.



2) Place plow in front of snow blower make sure it's place equally from both sides. Take template that has been provided for you, place it at the edge & middle of the housing and mark your holes.

3) Cut the red dotted line off the template. Then drill a 5/16 hole.

4) Mount your brackets underneath the blower housing with your bolt and large rubbers.

RUBBER MOUNT



Rubber mounts have two different face, oval and flat. Oval sits on top of the bracket. The flat side sits on the bottom of the snow blower. Rotate the rubber on the top of bracket until the correct position is achieved. Look at picture.

5) Place knobs on top of the housing and tighten the brackets to the correct angle of the plow. Adjust the height of the squeegee so it hovers flat from the ground. (**Note plow should be angled 90 degrees from the ground**).

6) Place the two angling (L shape) rubbers on the housing and adjust where the plow touches the housing. The rubber is to protect the snow blower and the plow. Also, functions has a angling device.

If your unit is 22 inches or 24 inches put in place the round rubber spacers to the L shape rubber against the plow.



If you have any question you can call 1.855-245-PLOW** or watch the [Youtube Video](#) for installation.**

Snow Plow Chart

SNOW BLOWER SIZE

24"
26"
27"
28"
30"
32"
33"
36"
38"
45"

PLOW SIZE

30"
34"
34"
34"
38"
38"
38"
48"
48"
48"